

**CL86** 

### **Closed-loop**

### **Stepper**

### 24~80VDC, 8.2A Peak, Closed-loop, No Tuning

- Closed-loop, eliminates loss of synchronization
- Broader operating range higher torque and higher speed
- Reduced motor heating and more efficient
- Smooth motion and super-low motor noise
- Do not need a high torque margin
- No Tuning and always stable
- Quick response, no delay and almost no settle time
- High torque at starting and low speed, high stiffness at standstill
- Offer servo-like performance at a much lower cost

### **Descriptions**

This Closed-loop Stepper offers an alternative for applications requiring high performance and high reliability when the servo was the only choice, while it remains cost-effective. The system includes a 2-phase stepper motor combined with a fully digital, high performance drive and an internal encoder which is used to close the position, velocity and current loops in real time, just like servo systems. It combines the best of servo and stepper motor technologies, and delivers unique capabilities and enhancements over both, while at a fraction of the cost of a servo system.

### **Applications**

Its great feature of quick response and no hunting make Leadshine's Closed-loop Stepper ideal for applications such as bonding and vision systems in which rapid motions with a short distance are required and hunting would be a problem. And it is ideal for applications where the equipment uses a belt-drive mechanism or otherwise has low rigidity and you don't want it to vibrate when stopping.



# **Specifications**


# **Electrical Specifications**

| Parameter             | Min | Typical | Max       | Unit |
|-----------------------|-----|---------|-----------|------|
| Input Voltage         | 24  | 48      | 80        | VDC  |
| Output Current        | 0   | -       | 8.2(Peak) | Α    |
| Pulse Input Frequency | 0   | -       | 200       | kHz  |
| Logic Signal Current  | 7   | 10      | 16        | mA   |
| Isolation Resistance  | 500 | -       | -         | ΜΩ   |

## **Operating Environment**

| Cooling               | Natural Cooling or Forced cooling |   |  |  |
|-----------------------|-----------------------------------|---|--|--|
|                       | Environment                       | Avoid dust, oil fog and corrosive             |  |  |
|                       | Storage Temperature               | -20℃ - 65℃ (-4°F - 149°F)                     |  |  |
| Operating Environment | Ambient Temperature               | $0^{\circ}$ C - $50^{\circ}$ C (32°F - 122°F) |  |  |
|                       | Humidity                          | 40%RH - 90%RH                                 |  |  |
|                       | Operating Temperature (Heat Sink) | <b>70</b> ℃ (158°F) Max                       |  |  |
| Storage Temperature   | -20 °C − 65 °C (-4 °F − 149 °F)   |   |  |  |
| Weight                | 580 g                             |   |  |  |

# **Mechanical Specifications**





#### **Protection Indications**

The green indicator turns on when power-up. When drive protection is activated, the red LED blinks periodicity to indicate the error type.

| Priority | Time(s) of<br>Blink | Sequence wave of RED LED | Description              |
|----------|---------------------|--------------------------|--------------------------|
| 1st      | 1                   | 5S<br>02S                | Over-current protection  |
| 2nd      | 2                   | 5S 5S                    | Over-voltage protection  |
| 3rd      | 7                   | 5S                       | Position Following Error |

# **Connectors and Pin Assignment**

The CL86 has four connectors, connector for control signals connections, connector for status signal connections, connector for encoder feedback and connector for power and motor connections.

|     | Control Signal Connector – Screw Terminal                                      |     |  |  |  |  |  |
|-----|--|-----|--|--|--|--|--|
| Pin | Name   | I/O | Description  |  |  |  |  |
| 1   | PUL+   | I   | <u>Pulse Signal</u> : In single pulse (pulse/direction) mode, this input represents pulse signal, each rising or falling edge active (software configurable, see Closed-loop Stepper software manual for more detail); In double pulse mode (software configurable), this input  |  |  |  |  |
| 2   | PUL-   | I   | represents clockwise (CW) pulse, active both at high level and low level. 4.5-24V when PUL-HIGH, 0-0.5V when PUL-LOW. For reliable response, pulse width should be longer than $2.5\mu s$ .  |  |  |  |  |
| 3   | DIR+   | ı   | <u>Direction Signal</u> : In single-pulse mode, this signal has low/high voltage levels, representing two directions of motor rotation. In double-pulse mode (software configurable), this signal is counter-clock (CCW) pulse, active both at high level and low level. For reliable motion   |  |  |  |  |
| 4   | DIR-   | I   | response, DIR signal should be ahead of PUL signal by $5\mu$ s at least. 4.5-24V when DIR-HIGH 0-0.5V when DIR-LOW. Please note that rotation direction is also related t motor-driver-encoder wiring match. Exchanging both the connection of two wires for a co and an encoder channel to the driver he connection will reverse motion direction. Or you can toggle the SW5 to reverse the motion direction. |  |  |  |  |
| 5   | ENA+   | I   | Enable Signal: This signal is used for enabling/disabling the driver. In default, high level (NPN control signal) for enabling the driver and low level for disabling the driver. Usually  |  |  |  |  |
| 6   | left UNCONNECTED (ENABLED). Please note that PNP and Differential control sign |     | left <b>UNCONNECTED</b> ( <b>ENABLED</b> ). Please note that PNP and Differential control signals are on the contrary, namely Low level for enabling. The active level of ENA signal is software configurable.   |  |  |  |  |



# **Connectors and Pin Assignment (Continued)**

|     |       |     | Status Signal Connector — Screw Terminal  |
|-----|-------|-----|---|
| Pin | Name  | I/O | Description   |
| 1   | Pend+ | 0   | <u>In-position Signal</u> : OC output signal, active when the difference between the actual position and the command position is zero. This port can sink or source 20mA current at 24V. The  |
| 2   | Pend- | 0   | resistance between Pend+ and Pend- is active at high impedance.   |
| 3   | ALM+  | 0   | <u>Alarm Signal</u> : OC output signal, active when one of the following protection is activated: over-voltage, over current and position following error. This port can sink or source 20mA current at 24V. In default, the resistance between ALM+ and ALM- is low impedance in |
| 4   | ALM-  | 0   | normal operation and become high when CL86 goes into error. The active level of alarm signal is software configurable. See Hybrid servo software operational manual for more detail.  |

| Encoder Feedback Connector – Screw Terminal |      |     |                          |  |  |
|---|------|-----|--------------------------|--|--|
| Pin   | Name | I/O | Description              |  |  |
| 1   | EB+  | I   | Encoder channel B+ input |  |  |
| 2   | EB-  | I   | Encoder channel B- input |  |  |
| 3   | EA+  | I   | Encoder channel A+ input |  |  |
| 4   | EA-  | I   | Encoder channel A- input |  |  |
| 5   | VCC  | 0   | +5V @ 100 mA max.        |  |  |
| 6   | EGND | GND | Signal ground            |  |  |

| Power and Motor Connector – Screw Terminal |          |     |   |  |                               |
|--|----------|-----|---|--|-------------------------------|
| Pin  | Name     | 1/0 | Description   |  |                               |
| 1  | A+       | 0   | Motor Phase A+  |  |                               |
| 2  | A-       | 0   | Motor Phase A-  |  |                               |
| 3  | B+       | 0   | Motor Phase B+  |  |                               |
| 4  | B-       | 0   | Motor Phase B-  |  |                               |
| _  | 5 +Vdc l |     | Power Supply Input (Positive)   |  | Power Supply Input (Positive) |
| 3  |          |     | 30-72VDC recommended, leaving rooms for voltage fluctuation and back-EMF. |  |                               |
| 6  | GND      | GND | Power Ground (Negative)   |  |                               |



### **RS232 Communication Port**

It is used to configure the close-loop current, open-loop current, position following error limit and etc. See Closed-loop Stepper software operational manual for more information.

|     | RS232 Communication Port |     |  |  |  |
|-----|--------------------------|-----|--|--|--|
| Pin | Name                     | I/O | Description                                  |  |  |
| 1   | NC                       | -   | Not connected.                               |  |  |
| 2   | +5V                      | 0   | +5V power only for STU (Simple Tuning Unit). |  |  |
| 3   | TxD                      | 0   | RS232 transmit.                              |  |  |
| 4   | GND                      | GND | Ground.                                      |  |  |
| 5   | RxD                      | 1   | RS232 receive.                               |  |  |
| 6   | NC                       | -   | Not connected.                               |  |  |



## **DIP Switch Settings**

### **Microstep Resolution (SW1-SW4)**

| Steps/Revolution                  | SW1 | SW2 | SW3 | SW4 |
|-----------------------------------|-----|-----|-----|-----|
| Software Configured (Default 200) | on  | on  | on  | on  |
| 800                               | off | on  | on  | on  |
| 1600                              | on  | off | on  | on  |
| 3200                              | off | off | on  | on  |
| 6400                              | on  | on  | off | on  |
| 12800                             | off | on  | off | on  |
| 25600                             | on  | off | off | on  |
| 51200                             | off | off | off | on  |
| 1000                              | on  | on  | on  | off |
| 2000                              | off | on  | on  | off |
| 4000                              | on  | off | on  | off |
| 5000                              | off | off | on  | off |
| 8000                              | on  | on  | off | off |
| 10000                             | off | on  | off | off |
| 20000                             | on  | off | off | off |
| 40000                             | off | off | off | off |



### **DIP Switch Settings (Continued)**

### **Motor Direction (SW5)**

|     | ON                           | OFF                          |
|-----|------------------------------|------------------------------|
| SW5 | Motor direction is positive. | Motor direction is negative. |

Note: The actual motor direction is also related to DIR level.

#### Motor Selection (SW6)

It is reserved for future use. Now it has no function for SW6.

#### **Current Control**

The motor current will be adjusted automatically regarding to the load or the stator-rotor relationship. However, the user can also configure the current in the tuning software. The configurable parameters include close-loop current, holding current, encoder resolution, micro step and etc. There are also PID parameters for the current loop, and they have been tuned for Leadshine's matching motors so the user does not need to tune them.

## **Closed-loop Motors**

CL86 can work with the following Leadshine Closed-loop motors:

|                        | ES-M22310(-S0605) | ES-M22320(-S0605) | Wiring Diagram |
|------------------------|-------------------|-------------------|----------------|
| Step Angle (Degree)    | 1.8               | 1.8               |                |
| Holding Torque (N.m)   | 4.0               | 8.0               | A+ / BLK       |
| Phase Current (A)      | 5.5               | 6.0               | 4 LEADS        |
| Phase Resistance (Ohm) | 0.46              | 0.44              | }              |
| Phase Inductance (mH)  | 4                 | 3.73              | A-/RED         |
| Inertia (g.cm²)        | 1500              | 2580              |                |
| Weight (Kg)            | 2.5               | 4.0               | B+/YEL B-/GRN  |
| Encoder (lines / Rev.) | 1000              | 1000              |                |

|                        | ES-M23440(-S1270) | ES-M23480(-S1270) | Wiring Diagram  |
|------------------------|-------------------|-------------------|-----------------|
| Step Angle (Degree)    | 1.8               | 1.8               |                 |
| Holding Torque (N.m)   | 4.0               | 8.0               | A+ / BLK        |
| Phase Current (A)      | 5.5               | 6.0               | 4 LEADS         |
| Phase Resistance (Ohm) | 0.46              | 0.44              | } \             |
| Phase Inductance (mH)  | 4                 | 3.73              | A-/ RED         |
| Inertia (g.cm²)        | 1500              | 2580              |                 |
| Weight (Kg)            | 2.5               | 4.0               | B+ /YEL B- /BLU |
| Encoder (lines / Rev.) | 1000              | 1000              |                 |



### **Motor Encoder Cable Pin-Out**

#### ES-M22310(-S0605), ES-M22320(-S0605), ES-M23440(-S1270), ES-M23480(-S1270)


| Pin | Name | Wire Color | 1/0 | Description       |            |  |
|-----|------|------------|-----|-------------------|------------|--|
| 1   | EA+  | Black      | 0   | Channel A+ output | HDD15 Male |  |
| 2   | VCC  | Red        | - 1 | +5V power input   |            |  |
| 3   | GND  | White      | GND | Ground            |            |  |
| 11  | EB+  | Yellow     | 0   | Channel B+ output |            |  |
| 12  | EB-  | Green      | 0   | Channel B- output |            |  |
| 13  | EA-  | Blue       | 0   | Channel A- output |            |  |

#### **Motor Encoder Extension Cable**



| Pin | Wire Color | Name | Description     | Pin | Wire Color | Name | Description |
|-----|------------|------|-----------------|-----|------------|------|-------------|
| 2   | Red        | VCC  | +5V power input | 12  | Green      | EB-  | Channel B-  |
| 3   | White      | GND  | +5V GND         | 1   | Black      | EA+  | Channel A+  |
| 11  | Yellow     | EB+  | Channel B+      | 13  | Blue       | EA-  | Channel A-  |


## **Typical Connections**




Connections to controller of sinking output



### **Typical Connections (Continued)**



Connections to controller of sourcing output



Connections to controller of differential output